




Removing HP Compaq dx2000MT CPU Cooler

Remove the CPU Cooler

Written By: Logan Pace



INTRODUCTION

This guide will show you how to remove the CPU Cooler on your HP Compaq dx2000MT.



TOOLS:

- [Anti-Static Wrist Strap](#) (1)
 - [Flathead Screwdriver](#) (1)
 - [Isopropyl Alcohol](#) (1)
 - [Phillips #2 Screwdriver](#) (1)
 - [T15 Torx Screwdriver](#) (1)
 - [High Content Rubbing Alcohol](#) (1)
-

Step 1 — Case Doors



- Turn off your computer and remove the power cable by pulling it straight out of its socket.

Step 2



- Remove the 2 Phillips #2 screws that secure the case door to the device.

Step 3





- Remove the side case door by pushing towards the rear of the device with your hand.
 - ⓘ This may take considerable force so keep pushing!
- Once you slide the door back, remove it by pulling it outwards from the device.

Step 4





- Remove the side case door by pushing towards the rear of the device with your hand.
 - ⓘ Once again, this may take considerable force.
- Once you slide the door back, remove it by pulling it outwards from the device.

Step 5 — CPU Cooler



- Remove the 3 pin power connector by pulling it towards the side of the device.


Step 6



- Unscrew the 4 Torx T15 screws holding the CPU Cooler in place.

⚠ Make sure to hold your cpu cooler when removing the screws. You don't want it to fall!

Step 7



- Remove the cpu cooler by pulling out towards the side of the device.
- ⚠ Make sure you do not touch where the cpu cooler makes contact with the processor! You could contaminate the layer of thermal paste that separates these components.
- ℹ When replacing your cpu cooler, make sure you clean the processor contact area on the cooler and processor with isopropyl rubbing alcohol.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 08:13:07 PM.